

# ace04\_process\_reads\_full

August 21, 2018

```
In [5]: # import packages
        from Bio.SeqIO.QualityIO import FastqGeneralIterator

In [6]: read_pair1 = open("../data/c_burnetii_1k_R1.fastq", "r")
        read_pair2 = open("../data/c_burnetii_1k_R2.fastq", "r")

        filtered_read_pair1_out = open("../data/c_burnetii_1k_trim_R1.fastq", "w")
        filtered_read_pair2_out = open("../data/c_burnetii_1k_trim_R2.fastq", "w")

In [7]: # instantiate a fastq iterator using Biopython package
        f_iter1 = FastqGeneralIterator(read_pair1)
        f_iter2 = FastqGeneralIterator(read_pair2)

In [12]: # settings, constants
        LENGTH = 60
        QUAL = 35
        BARCODE_LENGTH = 0

In [13]: # iterate through reads, in lock step, quality trim
        for (title1, seq1, qual1), (title2, seq2, qual2) in zip(f_iter1, f_iter2): #zip does

            # do not use reads with "Ns"
            if "N" not in seq1 and "N" not in seq2:

                # set flag to zero
                seq1_flag = 0
                seq2_flag = 0
                qual1_len = qual1[BARCODE_LENGTH:(LENGTH + BARCODE_LENGTH - 1)]
                qual2_len = qual2[BARCODE_LENGTH:(LENGTH + BARCODE_LENGTH - 1)]

                # check if quality score meets cutoff for both reads
                for i in qual1_len:
                    if ord(i)-33 < QUAL:
                        seq1_flag += 1

                for i in qual2_len:
                    if ord(i)-33 < QUAL:
                        seq2_flag += 1
```

```

    # only keep those reads that pass quality
    if seq1_flag == 0 and seq2_flag == 0:

        filtered_read_pair1_out.write("@%s\n%s\n+\n%s\n" % (title1, seq1[BARCODE_1], seq1[SEQUENCE_1], seq1[QUALITY_1]))
        filtered_read_pair2_out.write("@%s\n%s\n+\n%s\n" % (title2, seq2[BARCODE_1], seq2[SEQUENCE_1], seq2[QUALITY_1]))

# clean up
    filtered_read_pair1_out.close()
    filtered_read_pair2_out.close()
    read_pair1.close()
    read_pair2.close()

```